

112 - 11786 River Road, Richmond, BC V6X 3Z3

Tel: 604-270-0318 / 1-866-898-1232 Fax: 604-270-3210

Email: cet@cetproductions.bc.ca Website: www.cetproductions.bc.ca

Self Vinyl Installation Tutorial

Custom pre-spaced vinyl lettering, logos, stickers and decals can be cut and delivered to end-users for easy DIY installation. Adhesive vinyl can be applied to virtually any smooth non-porous surface.

You need:

- 1. Towel Paper towel is not preferred because paper dust may result unexpected bubbles
- 2. Scraper For removing previously applied vinyl and remaining adhesive dirt
- 3. Adhesive Removing Fluid Ready-made chemical for removing remaining old adhesive dirt
- 4. Squirt Bottle Filled with ready-made application fluid or DIY mixture of 80% water and 20% dish soap
- 5. Squeegee To remove air bubbles when applying
- 6. Heat Gun or Hair Dryer To speed up drying time

Steps:

1. Clean



- Scrape away all previously applied vinyl and remaining adhesive dirt
- Use damped towel to clean all dust on the surface
- 2. Peel



- Peel release paper backing
- Spray



- Spray application fluid on the adhesive side of vinyl and surface with squirt bottle
- 4. Position



- Position the sign to the surface while the sign and the surface are wet
- 5. Smooth



- Smooth the sign into position
- If the sign does not slide, try to add more application solution
- 6. Squeegee



Squeegee from center outwards to remove air bubbles